

Install Dowel & Cam Lock Screw on Left Panel & Right Panel;




Step 2:

Insert Top Panel、Bottom Panel & 3" Panel on Right Panel; Lock tight with Cam Lock;




Step 5:

Install Fixing nail(6 pcs) in the back;




Step 3:

Insert Back Panel;




Step 4:

Cover Left Panel Lock tight with Cam Lock;



Step 6:

Stand the cabinet up; Insert the shelf support on Left Panel & Right Panel,Install shelf;




ASSEMBLY INSTRUCTION

No.	PICTURE	ITE	M
1		Cam lo	ock
2	Co	Cam lo	ock screw
3		Dowel	
4	3	Shelf	support
No.	Part		QTY.
1	Right panel		1
2	Bottom panel 1		1
3	Top panel 1		1
4	3'' Panel 4		4
5	Back panel 1		1
6	Left panel 1		1
7	Shelf 1		1
			total 10


C1584F C1884F C2184F C2484F C3084F C3684F

Install Dowel & Cam Lock Screw on Left Panel & Right Panel;




Step 2:

Insert Top Panel、Bottom Panel & 3" Panel on Right Panel; Lock tight with Cam Lock;




Step 5:

Install Fixing nail(6 pcs) in the back;




Step 3:

Insert Back Panel;




Step 4:

Cover Left Panel Lock tight with Cam Lock;



Step 6:

Stand the cabinet up; Insert the shelf support on Left Panel & Right Panel,Install shelf;




ASSEMBLY INSTRUCTION

No.	PICTURE	ITE	EM
1		Cam lo	ck
2	Co	Cam lo	ck screw
3		Dowe I	
4	3	Shelf	support
No.	Part		QTY.
1	Right panel		1
2	Bottom panel		1
3	Top panel 1		1
4	3'' Panel 4		4
5	Back panel 1		1
6	Left panel 1		1
7	Shelf 1		1
			total 10

C1584DF C1884DF C2184DF C2484DF C3084DF C3684DF

Step 3:


Install Dowel & Cam Lock Screw on Left Panel、Right Panel、 Back Panel 1 & Back Panel 2;



Cover Back Panel 2 & Right Panel, Lock tight with Cam Lock;


Step 2:

Insert Top Panel 、 Bottom Panel 、
Toekick 1 & Toekick 2 on Back Panel 1,
Lock tight with Cam Lock;




Step 4:

Cover Left Panel Lock tight with Cam Lock;



Step 5:

Stand the cabinet up; Insert the shelf support on Left Panel 、 Right Panel、Back Panel 1 & Back Panel 2,Install shelf;




ASSEMBLY INSTRUCTION

No.	PICTURE	ITEM	
1	8	Cam lock	
2	· Co	Cam lock s	crew
3		Dowel	
4	3	Shelf supp	ort
No.	Part QTY		QTY.
1	Right panel 1		1
2	Back panel 1 1		1
3	Bottom panel '		1
4	Top panel 1		1
5	Shelf 1		1
6	Toekick 1 1		1
7	Toekick 2 1		1
8	Back panel 2 1		1
9	Left panel 1		1


ER3084F ER3684F total 9

Install Dowel & Cam Lock Screw on Left Panel & Right Panel;




Step 2:

Insert Top Panel & Bottom Panel & 3" Panel on Right Panel; Lock tight with Cam Lock;



Finish




ASSEMBLY INSTRUCTION

No.	PICTURE	ITI	EM
1	P	Cam I	ock
2	· Co	Cam lock screw	
3	Ĵ	Dowe I	
No.	Part QTY.		
NO.	rart QII.		GII.
1	Right panel 1		1
2	Bottom panel 1		1
3	Top panel 1		
4	3'' Panel 2		
5	Back panel 1		1
6	Left panel 1		1
			total 7

C1521 C1521D C1821 C2121 C1821D C2421 C3021 C3021D C3621D


Step 3:

Insert Back Panel;



Step 4:


Cover Left Panel Lock tight with Cam Lock;



C3621


Step 3:

Install Dowel & Cam Lock Screw on Left Panel、Right Panel、 Back Panel 1 & Back Panel 2;




Step 2:


Insert Top Panel 、 Bottom Panel 、 on Back Panel 1
Lock tight with Cam Lock;



Finish;




Cover Back Panel 2 & Right Panel, Lock tight with Cam Lock;



Step 4:

Cover Left Panel Lock tight with Cam Lock;




ASSEMBLY INSTRUCTION

No.	PICTURE	ITEM
1		Cam lock
2	Ca	Cam lock screw
3	Î	Dowe I

No.	Part	QTY.
1	Right panel	1
2	Back panel 1	1
3	Bottom panel	1
4	Top panel	1
5	Back panel 2	1
6	Left panel	1
	tota	l 6


ER3021 ER3621

Install Dowel & Cam Lock Screw on Left Panel & Right Panel;




Step 2:

Connect Left Panel with Back Panel & Font Panel; Lock tight with Cam Lock;




Step 3:

Insert Bottom Panel from right side;




Step 4:

Cover Right Panel,Lock tight with Cam Lock;




Step 5:

Install Drawer Face, Screw from inside of drawer box;



Finish;





ASSEMBLY INSTRUCTION


PICTURE


1		Cam loo	ck	
2	· Co	Cam lo	ck s	crew
3	•	Screw		
	_			
No.	Par	t		QTY.
1	Left pa	ane l		1
2	Back pa	ane l		1
3	Right p	anel		1
4	Bottom I	^D ane l		1
5	Front P	anel		1
6	Drawer	Face		1
			tota	al 6


DK15N	DK15DN
DK18N	DK18DN
DK21N	DK21DN
DK24N	DK24DN
DK30N	DK30DN
DK36N	DK36DN
DK15H	DK15DH
DK18H	DK18DH
DK21H	DK21DH
DK24H	DK24DH
DK30H	DK30DH
DK36H	DK36DH











Connect LED LIGHTING to Transformer. (Extension wires could be added when needed).

Sten 2

Connect Joint control box to Transformer.

Step 3

Connect Touch switch to Joint control box.